Important!

Freezer Section Loading Instructions

When loading the freezer section, make certain that food packages are placed approximately 5½" from the front of the cabinet to provide for the space required by the freezer door shelf when the freezer door is closed. Food packages extending beyond this point will interfere with proper closing of the door. When this happens, excessive ice build up or breakage of the inner door panel will occur.



Part No. 529819 4-60 Printed In U.S.A.